

Fixtures are classified for insulated ceilings-type IC and type T-and for suspended ceilings-type S. To insure safe and reliable operations. Make sure the fixture corre-sponds to the carefully before beginning installation

Before attempting installation of any recessed lighting fixture check your local electrical code. This code sets the wiring standards for your locality and should be carefully studied before starting work

Insulated Ceiling

The insulted ceiling or I.C. approved recessed fixture is one that can be installed in direct contact with insulation





NEW CONSTRUCTION INSTALLATION.

1. FASTENING FIXTURE TO CEILING

Joist-type ceiling-extend bar hangers to fit between joists. Position fixture temporarily by hammering "Nail" into joists. (Drawing 1), then secure permanently with nails. Hangers should be level with bottom of joists.


Suspended(T-bar) ceilings-extend bar hangers 1" past T-bars, then rest fixture on T-bars. Secure fixture to T-bars with wire (Drawing 2).






2. ELECTRICAL CONNECTION

Open the Juntion Box cover and connect the wires in the same color. Please refer to the details of wires shown below. Close J-Box cover after wiring.





3. CUTTING A HOLE


Locate the center of proposed opening on your tile or ceiling material and mark it. Rounds: Use a compass to draw a circle shown below diameter around the center point. Cut along this circular line








4. DIMMER SWITCH WIRING





5. ENGAGE THE LIGHT ENGINE

Engage the light engine support cable hook with the hook from frame side.

6. CONNECT THE LIGHT ENGINE

Connect light engine connector to the flex connector of the frame and insert the light engine onto the frame. Avoid hot plugging

